GAIME

Age 14+

QUICK START GUIDE

BASIC PACK | TD-001-W

Game Pad Mini

Thank you for purchasing G1 MINI. Before use, please read this user manual carefully and keep it for future reference. After reading, kindly keep the manual in a safe place for future reference.

For your safety, the following indications are provided for this product.

⚠ **CAUTION** Failure to observe the precautions indicated in this guide may result in personal injury, including death or serious injury due to fire or electric shock.

⚠ **ATTENTION** Failure to observe the precautions indicated in this guide may result in electric shock or other accidents that may cause injury or damage to surrounding household goods.

TASSEL

Contacts for products:
www.tassel.com
support@tasseline.com

Contents (TD-001-W)

Mini Console	1 piece	HD Cable (1m)	1 piece
Quick Start Guide	1 piece	Quick Start Guide	1 piece
USB Power cable	1 piece		

IMPORTANT INFORMATION
Only the controllers that are fully available USB-compatible of adapter is required. Please ensure it has a Light Sensor Card and provides an output of 5V/3A (USB Power Delivery).

SUN LATCHET

CON Button / Game Select

MINI CONSOLE

HDMI
(4K Adapter: 1080P HD Output)

GETTING STARTED

1. Connect the power cable to the G1 MINI Mini Console and then to the AC Power Adapter (Not included).
2. Connect the USB-compatible Game Pad to the G1 MINI Mini Console.
3. Connect your G1 MINI Sun / Pinstripe to the G1 MINI Mini Console (Pinstripe sold separately)

HDMI
(4K Adapter: 1080P HD Output)

PLAYING

1. Insert the power button for 1 second (Blue LED will turn on). The booting screen will appear on the screen.
2. Watch the Pre-installed video and then follow the calibration process (Ready).
3. Ready to START! Enjoy the game to play.

HDMI
(4K Adapter: 1080P HD Output)

The GAME system uses "USB screen detection" and if other screens are visible to the camera, this may affect the performance of the gun calibration.

Begin light reflecting onto the screen may affect gun calibration performance. If this happens, place the console in turn off any nearby lights so that only the screen is visible to the gun camera.

CAUTION
A poor Y-line is a weak relief setting, then enabling it may enhance the product performance.

ACCESSORY CONNECTION
The Mini Console has 2x Type-C USB ports allowing you to connect:
1. Gun Sun / Pinstripe
2. Gun and 1 Pinstripe (Pinstripe sold separately)

50" - 55" = 9 ft / 2m	32" - 40" = 6 ft
55" - 80" = 2 ½ feet	80" - 84+ = 8 feet

Recommended Gaming Area
Ensure the screen is visible to the gun as standing the recommended distance from the TV. Ensure the screen is visible to the gun at all times. Do not place the gun in front of the screen.

This ensure your middle screen camera is continuously visible of it is required to check the camera view. If your phone camera can see the full screen then the distance from the screen will be OK.

CALIBRATION INSTRUCTIONS

⚠ **IMPORTANT**

IMPORTANT: Indoor Lighting Condition is essential for the G1 MINI System to work correctly. Please take your time and follow the steps carefully. Rushing the calibration process and not accurately calibrating the gun will affect your gaming experience.

Why Calibration is Needed?
Each TV has different brightness and contrast. A calibration sequence will run on the Lightgun can "learn" your playing environment. This ensures your shots register correctly on screen.



Place your gun **back from red eye** sensor.

Tap **okay, aimmer alone** button on your screen, calibration will start.

Point at the same crosshair as the calibrating and while playing for best results.

Step 1 - Instructions
- Follow the on-screen reminding you of the importance of calibration.
- Align the two aiming sights of your gun with the target crosshair.
- **Pull the trigger to continue.**

Step 2 - Shoot Target instructions
- Crosshair will display & begin to move in sequence.
- Your task is to shoot the center of each target three times (Total 9 shots).
- If you miss a shot or shoot too quickly, the system will restart calibration.
- **When ready, pull the trigger to begin calibration.**

Step 3 - Calibration in Progress
- The first target will appear.
- Shoot the center of the target.
- Ideally five three accurate shots at the center of each target before moving to the next.

Recalibration Options

- If the initial calibration sequence is off, you can recalibrate.
- Analog and mouse mode are provided.
- Or, assign the game and hide the X button to restart calibration for that gun.

Once calibration is complete, your gun is ready for gameplay!

ABOUT THE DEVICES

Power Button
Hold the power button for one second to turn on the unit and the power indicator will turn on. To turn off the unit, press the power button once and the power indicator will turn off.
Hold the power button for 3 seconds to enter the pairing mode. Release the power button when the light on the game selection screen.
Hold the power button for 8 seconds will reset all inflight scores.
If no buttons on the gun controller are pressed for a period of 1 minute the gun will go into SLEEP MODE. Pressing any button will wake the gun back up. Please press the trigger or any button once. This will return you to the last active setting.

PLEASE NOTE: When pairing the guns, make sure to turn off the power on the console before unpairing the AC adapter or USB cable to prevent damage to the device or data corruption.
Please connect the USB power cable to the console first.

Mini Console

Connections of each button are as follows:

Trigger Button
Used for shooting games, advancing to the next screen, shooting etc.

Cam Button (Grab)
Used for Grab in shooting cradle.
Long press cheat to return the Game Select Menu (in Pause mode only).

Pause Button
Short press cheat to pause the game.
Long press cheat to restart the game (in Pause mode only).

A/B Button
Used for additional actions such as standing or ducking in shooting games and select the game and select the used to adjust the calibration screen.

Gun Controller

Shooting mis-con allows you to turn the Cam Button ON / OFF in the game.

PRIVACY INFORMATION

Disclaimer:
Our product includes an integrated camera component used solely for internal functionality (e.g., calibration, gameplay). It operates locally. The camera does not record, stream, or transmit any images or video. It does not collect personal data or affect user privacy in any way.

SETTINGS

Only gun(s) paired to the G1 MINI Console can be adjusted in the SETTINGS MENU. The table below shows how the gun is paired and allows for adjusting these settings.

Settings Table

Gun Paired	Settings			
	Cursor	Sensitivity	Delay	Vibration	Input
Gun 1	Lime	3	2	1	Mouse

Pair Instructions
Adjusting this level affects how bright and visually striking a screen flash effect appears.

Shooting mis-con allows you to turn the Cam Button ON / OFF in the game.

HEALTH ALERTS

⚠ **WARNING**

Photosensitive Seizure Warning
This product includes flashing light/strobe-style visuals, including flashing lights, rapid explosions, and fast-moving visuals. These elements may trigger seizures in photosensitive individuals.

If you or someone in your family has a history of epilepsy or seizures, we strongly recommend consulting a doctor before playing.

Stop playing immediately and seek medical attention if you experience any symptoms.

⚠ **WARNING**

Immediately stop playing if you experience any problematic symptoms, such as headaches, dizziness, nausea, eye strain, muscle twitching, or loss of consciousness. If these symptoms persist, do not resume play. Your eyes, hands, arms, or legs, do not start playing again after the symptoms improve until you consult your doctor.

⚠ **WARNING**

- Play in a well-lit room and avoid sitting too close to the screen.
- Do not play when you are feeling tired or sleepy.
- Take regular breaks while playing.
- If you experience any discomfort, stop immediately.

PRECAUTIONS

⚠ **WARNING**

Do not use the product as a high-precision electronic device, and make sure to consider the following material damage risks.

⚠ **WARNING**

- Do not place the AC adapter (not included) before the main unit is powered down.
- Do not place the AC adapter (not included) in a place where it is easy to trip over the cable.
- Do not place heavy objects such as laptops or mirrors near to place the product or any of its parts.
- Do not place the product near a heat source, such as a heater, or in a place where it is exposed to direct sunlight, and avoid use of the product in a place where it is exposed to high temperatures and humidity.
- Do not place the product in a place where it is exposed to high, near stones or other places that may cause damage to the product.
- Place the device on a flat surface and ensure the ventilation holes are not covered.
- Do not use the product in the rain.
- Do not use the product in dusty, humid and wet environments.
- Do not place the product in a place where it is exposed to direct sunlight.
- Do not drop or hit the set or any of its parts.
- Do not place the product near a heat source, such as a stove.
- Keep the connectors clean and check them for damages regularly.
- Do not disassemble or modify the product or accessories.

LIMITED WARRANTY

This product is warranted against defects in materials and workmanship for a period of one (1) year from the original purchase date. This warranty does not cover damage or defects caused by improper use or accidents.

What is Covered:
- Defects in materials and workmanship under normal use and service.
- Repair or replacement of the defective product at our discretion.

What is Not Covered:
- Damage caused by misuse, abuse, accidents, or unauthorized modifications.
- Damage caused by improper installation or maintenance.
- Damage caused by third-party accessories or software.
- Damage caused by external factors, such as fire, flood, or other acts of nature.

Customer's duties:
- Ensure that the product that is not covered by the warranty.
- Contact our support team before returning any product.

To Make a Warranty Claim:
- Contact our support team with a description of the warranty period to report a defect.
- Provide a copy of the original proof of purchase.
- Our team will provide instructions on the process for shipping a warranty claim.
- You may be required to return the defective product to us for inspection.

LIMITATION OF LIABILITY

To the fullest extent permitted by law, TASSEL STORE shall not be liable for any consequential or incidental damages, including but not limited to, loss of profits, loss of data, or loss of use of the product.

DISCLAIMER

The warranty is the sole and exclusive remedy for any breach of the warranty. TASSEL STORE does not make any other warranties, express or implied, including but not limited to, any implied warranties of merchantability or fitness for a particular purpose.

PRODUCT SPECIFICATIONS FAQ

Is this plug and play, or do I need to install drivers?
It is plug & play and play, you do not need to install any drivers. This is the advantage of using USB-C.

Can I use the G1 MINI Gun on another console?
No, it is specifically designed for the G1 MINI Mini Console.

Is Free Cinema included game?
Yes, it is pre-installed on the console. To ensure a plug-and-play experience, we recommend purchasing G1 MINI TWO (TWO) / PRIMEVAL (1-4) MINI / TAKE (TWO) / LETMOUT, Both versions, ensure compatibility with the Free Cinema game. Other G1 MINI product has been pre-installed.

Will more games be added to the G1 MINI ?
Yes, we plan to add more games in the future.

Does G1 MINI work with my OLED Screen?
Yes, it supports most modern TV types, including OLED, QLED and LCD.

Will G1 MINI work on my CRT TV?
G1 MINI is not suitable for CRT TV, but TASSEL thanks for playing our officially licensed Pinstripe CRT TV.

Can I use the G1 MINI with a projector?
Generally, yes, it should work with most projectors. However, we cannot guarantee compatibility with every model, due to lag or legacy CC TV issues(Rare), require you to be at least 3m away, depending on the projector's specs. We recommend testing it first.

Can I calibrate my G1 MINI gun?
Yes, it supports both analog and mouse modes, offer leading in will give you an easy and radio-silver screen, you will enjoy pixel-perfect hinge times. Super-wide, super-wide, very effective if you have a wide screen, or if you want to play with friends, it's the best choice. Our Sun / Latch / Latch Mini, **Can not based pixel perfect, but it's very accurate.**

Do I need to pair the gun every time I turn on the console?
Do I need to pair sensors on my screen to use G1 MINI?

Hope, that's the theory of G1 MINI !! Very simply plug a HD Sun cable into the G1 MINI Mini-Console and play!

What cable if fewer ports on my console?
You will need a USB-C Power adapter that provides a minimum 5V at 3A (15W output). Most modern USB-C power adapters meet this requirement. Ensure the adapter is high-quality and capable of safely and efficiently providing sufficient power stability to power G1 MINI.

Can I use the G1 MINI with a 4K TV?
As part of our environment conservation efforts only the Ultimate Pack includes an AC Adapter as standard. The Ultimate Pack also includes a 4K HDMI adapter. The Basic Pack does not. If you use a compatible Type-C adapter, you always can to take advantage of 4K.

What colors are available for the G1 MINI ?
We offer a variety of colors for the G1 MINI Mini-Console Black in compliance with written and unwritten gun regulations, user expectations. We will provide an update on bringing more colors to the market.

Can you turn thumbs up and off on the G1 MINI ?
Yes, change the "Input Cursor" option in the A/B part of the gun to the desired option.

GENERAL FAQ

Is customer support available if I have issues?
Yes, our dedicated support team is available to assist you via email. Please visit www.mygame.com/support and fill out our support form. We have a 24 hour, 7 days a week service, and will aim to reply to you within 24 hours.

Is there a community or forum where I can ask for help or share advice?
Yes, we have a vibrant community on our official Discord server where users share tips, ask questions, and enjoy fellow gamers.

Terms and Conditions
You can find our Terms and Conditions in the **mygame.com** website.

Check out the G1 MINI community on Discord / hang out with other members and share how you and had out.

GAIME

TASSEL

MYGAIME.COM

TASSEL STORE™ is a registered trademark of TASSEL STORE CO., LTD. All rights reserved
Other trademarks are the property of their respective owners.
THE GAME CO. Inc. Patent Pending

RoHS

Artwork v1